



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	598	Handle bolt washer	1166	Embedded clip
178	Set plate nail	601	The small washer	1194	High speed pinion gear
185	"E" washer	604	Spool shaft spring	1251	Small ring
202	Handle knob screw 1	630	"O" ring	1319	Drive shaft
207	Push slice screw	656	Spool spring washer	1323	Reel foot screws
211	Set plate screws	665	Big ring	1325	Rear drag plate
215	Cover screw	668	Side plate screws	1327	Drag plate
310	Slingshot meson	670	Close cover screws	1328	Reel foot cannulation
364	Handle knob screw 1	679	Button washer	1429	Drag plate washer
378	Ball bearing (S106)	680	Drive shaft coat washer	1431	Fixed plate pin
381	Ball bearing (S606)	698	Spool ring	1432	Drag plate undersleeve
384	Ball bearing (S6700)	699	Set plate	1433	Pin with small teeth
390	Ball bearing (S696)	714	T handle nail	1434	Spring cover for silence
395	One-way bearing	772	Handle bolt	1436	Anti-reverse ratchet
396	Handle washer	804	Sound spring plate	1437	Spool spring washer
417	Drag knob cover	831	Drive shaft coat	1439	Front drag plate
419	Pre-program key pin	873	Strike alert lever	1440	Drive gear-high speed
420	Sound nail	910	Anti-reverse dog	1555	Sound coat
424	Spool shaft screw	976	Friction ring	1556	Bearing cover
425	Screw embedded clip	1144	Handle shaft coat	1560	Spool shaft
426	Screw for bearing cover	1147	Knob upper covre	1561	Right plate
428	Sound nail spring	1148	Knob bottom covre	1562	Frame
429	Bearing ring	1149	Main Knob	1563	Drag control lever
430	Drag control lever washer	1150	Drive shield	1564	Pre-program plate
431	"O" ring	1151	Lock set	1565	Pre-program key
453	Handle knob screw 2	1153	Cover	1566	Drag tension knob
493	Sound spring	1155	Handle arm		
519	Sound gear	1157	Spool cannulation		
539	Alarm sound gear	1159	Reel foot		
546	Drive shaft washer	1162	Spool		
564	Sound spring pin	1164	Close cover		