



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	453	Handle knob screw 2	910	Anti-reverse dog
178	Set plate nail	493	Sound spring	976	Friction ring
185	"E" washer	519	Sound gear	1015	Drive gear-high speed
202	Handle knob screw 1	539	Alarm sound gear	1016	Spring cover for silence
207	Push slice screw	546	Drive shaft washer	1138	"C" washer
211	Set plate screws	564	Sound spring pin	1144	Handle shaft coat
215	Cover screw	573	High speed pinion gear	1147	Handle cover
310	Spring washer	598	Handle bolt washer	1148	Hander cover
364	Handle knob screw 1	601	The small washer	1149	Handle knob
378	Ball bearing (S106)	604	Spool shaft spring	1150	Drive shield
381	Ball bearing (S606)	630	"O" ring	1151	Lock set
384	Ball bearing (S6700)	655	Fixed plate	1153	Cover
390	Ball bearing (S696)	656	Spool spring washer	1155	Handle arm
395	One-way bearing	665	Big ring	1157	Spool bushing
396	Handle washer	666	Small ring	1159	Reel foot
397	Drive shaft	668	Side plate screws	1162	Spool
417	Drag knob cover	670	Close cover screws	1163	Drag control lever
418	Sound coat	672	Fixed plate screws	1164	Close cover
419	Pre-program key pin	679	Button washer	1165	Pre-program plate
420	Sound nail	680	Drive shaft coat washer	1166	Embedded clip
421	Bearing cover	698	Spool ring	1167	Sideplate
422	Spool spring washer	699	Set plate	1168	Frame
423	Drag plate washer	713	Anti-reverse ratchet	1182	Drag tension knob
424	Spool shaft screw	714	T handle nail	1323	Reel foot screws
425	Screw embedded clip	772	Handle bolt	1324	Spool shaft
426	Screw for bearing cover	804	Sound spring plate	1325	Rear drag plate
428	Sound nail spring	831	Drive shaft coat	1326	Front drag plate
429	Bearing ring	873	Strike alert lever	1327	Drag plate
430	Drag control lever washer	875	Pre-program key	1328	Reel foot insert
431	"O" ring	897	Drag plate undersleeve		