



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
43	Drive shaft washer	665	Big ring	1555	Sound coat
46	Reel foot screws	666	Small ring	1590	Handle lock ring
185	"E" washer	669	Side plate screws	1600	Drive shield
207	Push slice screw	670	Close cover screws	1601	Drag tension knob
211	Set plate screws	671	Spool shaft screw	1602	Handle shaft coat
215	Cover screw	673	Screw for bearing cover	1603	Main Knob
380	Ball bearing (S605)	679	Washer 2	1615	Bearing cover
384	Ball bearing (S6700)	680	Drive shaft coat washer	1616	Pre-program plate
388	Ball bearing (S85)	684	Drag plate	1617	Pre-program key
389	Ball bearing (S695)	698	Spool ring	1623	Drag adjustable washer
395	One-way bearing	772	Handle bolt	1624	Spool shaft spring
400	Drive shaft coat	792	Ball bearing (S624)	1706	Sound nail
401	"O" ring	804	Lever spring	1707	The sound nail springs
404	Friction spring	873	Strike alert lever	1793	Cover
406	Set plate	910	Anti-reverse dog	1794	Close cover
420	Sound nail	921	T handle nail	1795	Spool shaft
428	Sound nail spring	937	Alarm spring	1796	Spool cannulation
539	Alarm sound gear	943	Handle knob screw1	1797	High speed pinion gear
564	Alarm pin	946	Sound gear	1798	Anti-reverse ratchet
598	Handle bolt washer	1147	Handle cover	1799	Drive gear-high speed
601	Washer 1	1148	Hander cover	1800	Spool spring washer
627	Drag knob cover	1151	Lock set	1801	Ratcheting washer
630	"O" ring	1155	Handle arm	1802	Right plate
631	Wrench	1159	Reel foot	1803	Frame
639	Rear drag plate	1328	Reel foot spacer	1804	Spool
642	Front drag plate	1374	Handle knob screw 2	1805	Drag control lever
646	Pre-program key pin	1441	Drive shaft		
647	Set plate nail	1447	Pin with small teeth		
660	Bearing ring	1448	Drag plate undersleeve		
661	Handle washer	1449	Fixed plate pin		